

Fox Decoy



The realistic 3D fox decoy with a movable tail is made of weather-resistant EVA rubber. We recommend moving the decoy every 3–4 days to prevent birds from becoming accustomed to it.

Package Contents:

fox body, tail, mounting screw, 2 nuts, pole

Assembly

1) Unfold the fox.

Tip: You can place the fox outside in warm sunlight or immerse it in hot water. This will help the fox regain its intended shape. It may also be sufficient to leave the fox at ambient temperature for several hours so that it returns to its proper form.

Attaching the Tail:

2) Screw one nut onto the mounting screw until it is approximately 4.8 mm from the screw head. There is a screw hole on the back of the fox. Insert the screw through the hole from the outside. Tighten the second nut from the inside.

Place the tail onto the screw head and pull it downward until the tail is securely attached to the fox body.

Attaching the Pole:

3) Join the two pole sections together and rotate them by a quarter turn.

4) Insert the pole into the fox.

Tip: Place the fox on its back across two boards positioned slightly apart. This makes it easier to push the pointed end of the pole through.

Note: The fox may discolor when exposed to sunlight.